

**USER MANUAL**  
**HORIZONTAL PLATE LIFTING**  
**CLAMP**



***HANDELMAATSCHAPPIJ VLIERODAM B.V.***  
***NIJVERHEIDSWEG 21***

***POSTBUS 827***

***3160 AA RHOON***

***010 - 5018000***

***010 - 5013843***

***[www.vlierodam.nl](http://www.vlierodam.nl)***



HANDELMAATSCHAPPIJ VLIERODAM B.V.

Nijverheidsweg 21 , 3160 AA Rhoon

010-5018000

[www.vliero dam.nl](http://www.vliero dam.nl)

## USER MANUAL HORIZONTAL PLATE LIFTING CLAMP:

### Description:

Lifting clamps are applied for lifting and transporting all kinds of steel plates and are made of top quality alloyed steel.

Horizontal plate lifting clamps have specifically been designed for the horizontal lifting and transporting of non-bending steel plates. The clamps consist of a body, cam and cam pin. The cam also functions as a lifting shackle and ensures that the load is held firmly while it is being lifted.

Characteristic for a plate lifting clamp is that they function with a by the load generated clamping force. The friction between the load and the cams determine the safety. This is why the clamping jaws have tooth segments. For smooth surfaces which may not be damaged, like a stainless steel-plate, a plastic coating will be used on the cams.

Horizontal plate lifting clamps should always be used in pairs, or multiples thereof. In the latter case, however, preferably with a load spreader beam. When pairs or multiple clamps are used, each clamp should carry an equal part of the load.

### Safety instructions:

Please carefully read the safety instructions of this owner's manual before using the safety lifting clamp. In case of any doubts, please refer to your dealer!

- A horizontal plate lifting clamp must be inspected and tested every year by an authorized expert body.
- Never work with an untested clamp.
- Keep your distance when lifting and never stand under the load.
- Do not use the clamp if ( it has been ) damaged.
- A damaged clamp must be repaired by a producer notified body or person.
- Never lift more than one plate at a time.
- Never lift plates heavier than the working load limit ( WLL ) , as indicated on the clamp and in the test certificate.
- Do not lift plates which are thicker or thinner than the jaw opening, as indicated on the clamp and in the test certificate.
- When using a number of lifting clamps at the same time, please provide lifting slings or chains of a sufficient length to ensure that the angle between the slings or chains never exceeds 60°.
- When simultaneously operating a number of lifting clamps time side by side, please use a lifting beam ( equalizer) and lifting slings or chains of a sufficient length to ensure that the lifting shackles on the clamps are never subjected to lateral load.
- Do not place the clamp on tapered or conical sections of the plate or structure to be lifted.
- Remove all grease, oil, dirt, corrosion and mill scale from the plate at the point where the clamp is to be attached.
- Ensure that the clamp(s) is (are) positioned so as to balance the load when it is being lifted.
- The surface hardness of the plate must not exceed 37 Hrc ( 345 Hb, 1166 N/mm<sup>2</sup>), unless otherwise stated.
- The clamp is only suitable for use in normal atmospheric conditions.

### Warnings:

- Ensure that the cam can never be subjected to lateral load.
- A free fall or uncontrolled swaying at the crane hook resulting in objects being struck, may cause impact damage to the clamp. If this happens check whether the clamp is still in good working order before using it.
- Lifting clamps are not suitable for creating permanent joints.
- Do not modify the clamp (by welding, grinding, etc. ), as this can adversely affect its operation and safety, thereby nullifying any forms of guarantee and product liability.
- The clamps can be loaded laterally at a maximum angle of 15°, only when they are not loaded more than the maximum WLL and the permitted top angle. The capacity of the clamps has been calculated on basis of a maximum top angle of 60°. In case of situations with larger top angles, then the WLL should be reduced proportionally.

### Lifting:

- Check whether the working load limit ( WLL ) of the clamp is sufficient for the load created in the lifting situation. Note: The WLL is shown on the lifting clamp.
- Attach the lifting clamp to the hoisting mechanism either by means of a:  
safety shackle directly to a crane hook;  
coupling link or D-shackle;  
sling or chain, if necessary in conjunction with a coupling link or D-shackle.
- Ensure that all attachments have been tested and are of the correct tonnage. Make sure that coupling links and shackles are large



HANDELMAATSCHAPPIJ VLIERODAM B.V.

Nijverheidsweg 21 , 3160 AA Rhoon

010-5018000

[www.vlierodam.nl](http://www.vlierodam.nl)

- enough to allow the clamp to move freely in the hook.
- Check whether the clamp has any visible damage.
- Check whether the clamp opens and closes smoothly.
- Check whether the teeth of the cam are free from dirt, and if necessary clean with a wire brush.
- Remove any grease , dirt and mill scale from the plate at the site of the lifting clamp.
- Open the clamp.
- Place the jaws as far as they will go over the plate, making sure that the clamp is positioned so as to balance the load when it is being lifted.
- Lift gently so that the lifting force can be applied; check whether the clamp is rotating or tilting.
- Ensure that the load is in a stable position.